25W POWER MEGAPHONE

User's Manual

Congratulations on your Sunforce Purchase. This product is designed to the highest technical specifications and standards. It will supply years of maintenance free use. Please read these instructions thoroughly prior to use, then store in a safe place for future reference. If at any time you are unclear about this product, or require further assistance please do not hesitate to contact our trained professionals operating the customer support line 1-888-478-6435 or email to info@sunforceproducts.com

SPECIFICATIONS

Power Output: 25w Rated / 50w Max
Voice Range: 0.7 km
Power Source: 8 x UM-1 Cells
Working Voltage: DC 12v
Microphone: Unidirectional
Dimensions: Horn Dia.230mm, Length350mm
Weight: 1.5 kg without cells

OPERATION

Open the back cover. Remove the plastic battery sleeve and insert 8 nos. UM-1 cells with correct polarity, insert the sleeve into the battery compartment according to the instructions in the compartment. Then close the back cover until it locks. Now your megaphone is ready for action.

To activate the megaphone, switch the button to 'TALK' on the side of the detachable microphone, or press the button on the grip.

When using the megaphone, place your lips as close as possible to the detachable microphone. Adjust the volume control to the desired level without causing any howling or feedback.

Press the red siren button on detachable microphone to activate the emergency siren. Pressing the button again will turn off the siren.

Before recording, switch the button to the 'TALK' position, adjust the volume control to max, then press the 'REC' button, the 'REC' indicator light will flash twice. Now the recording function is ready. Speak into the microphone to record. To finish or stop the recording, press the 'REC' button again.
To play recording in a loop, press the 'PLAY' button. While playing, the indicator light will flash. To stop, press 'PLAY' button again, the indicator light will stop flashing.

PRECAUTIONS

- Ensure correct polarity of cells
- When the megaphone is not in use for a long period, remove the dry cells
- Drained cells will not give sufficient sound volume
- Replace cells at regular intervals, for optimum result

NOTICE: If the recording doesn't work well, please do as below: Press 'REC' button, the recording indicator light will flash, hold down until the light stops flashing for more than 5 seconds. Release the recording button and then switch to 'OFF'. The recording function is reset. Record again as in instructions above.

Warranty:

This product is covered under a one year limited warranty. Sunforce Products Inc. warrants to the original purchaser that this product is free from defects in materieals and workmanship for the period of one year warranty from date of purchase.
To obtain warranty service please contact Sunforce Products for further instructions at 1-888-478-6435 or email info@sunforceproducts.com. Proof of purchase including date, and expiration of complaint is required for warranty service.

For more information or technical support
1-888-478-6435
www.sunforceproducts.com
info@sunforceproducts.com
PMP041811